


V1.25
DIN A2

The current and voltage depends on the motor drivers, motors and other devices you want to use.

Working with 110 or 220 volts is life-threatening!
Please have the work carried out by a specialist.



Spindle

If you do not need the manual spindle control, connect light blue (1) to green (2).

1
2

on / off

Speed

10k Ω

Inverter

HY01D523B

Analogue Joy stick

GND 5V X Y Z

Select Joystick via SUB-D 25 or old (default) output.

Tip!
Jog Wheel / Manual control Connection, with or without Joystick. Have a look at the other PDF files for more info.

www.arduinoclub.shop

Start **Program** **Stop**

Monitor the status of your limit switches.

PNP Sensor NC or NO

SIG 6V

GND

X1 Y1 Z1


NO connection, the next page shows NC connection.

Mechanical Sensor - Normally Closed

X1 Y1 Z1

Tip!
Look in our shop, the switches we sell you are very accurate.

Speed- & Feed override
If you're using a jog wheel, you can't connect that.



The data serve as an example.

- Version: Mono
- Resistance: 10k Ohm
- Structure: linear
- Rotation angle: 280° or greater
- Nominal voltage: from 5VDC
- Nominal voltage: from 5VAC

Tip!
If the direction of rotation is not correct you can change the blue cable with the black cable.

Attention !!

Please consider that the Nano, the control card or the software could fail, therefore the emergency stop is mounted in front of all other devices and switches off the whole machine.

EMERGENCY STOP

PNP Sensor NC

